

Allworx Px 6/2 Expander

Increase the power of your Allworx 6x, 48x and 24x phone systems with the cost-effective Allworx Px 6/2 Expander. Use up to three Expanders simultaneously to add more FXO ports and FXS ports to your 6x, 48x or 24x system:



Each Allworx Px 6/2 Expander includes:

- Six (6) dedicated loop start FXO ports (e.g. traditional telephone lines - Central Office PSTN service)
- Two (2) dedicated internal FXS ports (e.g. analog phones & fax machines, alarm systems)
- Easy plug-n-play connection
- Ability to connect up to three (3) Px units per Allworx System
- Fully integrated graphical user interface
- LED indicators for port status monitoring

Each Px 6/2 Expander requires:

- Installation of Allworx System Software 6.9 or later
- Installation of the Allworx Internet Call Access Key for servers running software 6.9 and 7.0
- Systems running system software 7.1 and beyond do not require an Internet Call Access Key