

## Change CCR Tree



Figure 1

### Step 1 – Disable CCR Tree

Feature 983

Log: 120000 or 1020000

Admin  
MBOX AA OTHR

Auto Atdt Admin  
GRTG TABLE LINES

Grtg Table: 1  
RETRY OK

AA Menu Prompt: N  
CHNG REC OK

Morning: 1, 2, 3, 4 (consecutive)  
CHNG PLAY NEXT

Lang pref: pri  
CHNG NEXT

Atdt: 221  
CHNG NEXT

CCR Tree: 1  
CHNG OK

CCR Tree: 1  
DISABLE OK

Tree disabled

CCR Tree: disabled  
CHNG OK

Press \* \*

Continue to next step ...

## CJ Tel Communications Ltd.

For Sales or Service Call: (403) 274-7774

[info@cjtelcommunications.com](mailto:info@cjtelcommunications.com)

### Step 2 – Change CCR Tree

Admin  
MBOX AA OTHR

Admin  
GLIST CCR

CCR Admin  
ADMIN

CCR Tree: 1  
RETRY OK

Tree: 1  
CHNG PRINT QUIT

Path: (0 – 8) ←  
(0 = Main Menu Recording)  
(1 – 8 = Tree options)  
RETRY END OK

0 Home/Menu  
REC OTHR OK

Primary rec?  
REC PLAY NEXT

Primary rec?  
REC PLAY NEXT

Rec pri prompt:  
RETRY OK

Accept prompt?  
RETRY PLAY OK

Press \* **OR Return to -^**

RETRY END OK

Tree: 1  
SAVE PRINT QUIT

Save as Tree 1  
YES OTHR QUIT

Tree Saved  
Press \* \*

Continue to next step ...

## Change CCR Tree

### Step 3 – Enable CCR Tree

Admin  
MBOX AA OTHR

Auto Atdt Admin  
GRTG TABLE LINES

Grtg Table: 1  
RETRY OK

AA Menu Prompt: N  
CHNG REC OK

Morning: 1  
CHNG PLAY NEXT  
(Press **NEXT** 6 times)

Lang pref: pri  
CHNG NEXT

Atdt: 221  
CHNG NEXT

CCR Tree: DISABLED  
CHNG OK

CCR Tree: 1  
OK

Tree Enabled

Rls